

Compression fitting installation

1. Install PVC pipe tee(part# PPT) or drill and tap 1/8" NPT hole in pipe for compression fitting.
2. Feed heat cable through both pieces of the compression fitting.
3. Wrap cotton packing around heat cable and between the two piece compression fitting.
4. Tighten the upper piece of the compression fitting into the lower piece securing the cotton packing around the cable.
5. Install the compression fitting into pipe to complete the installation.

