



Bullet Proof Designs
500 S Lincoln Ave
Raymore, MO 64083
(816) 695-3784

FITMENT:

KTM

2015 KTM FACTORY EDITION 250-450

2016 KTM SXF/XCF MODELS AND SX125-150 MODELS AND Factory Edition MODELS

2017-2023 KTM ALL 125-500 MODELS FITS NEW 2019-2022 TPI MODELS

Husqvarna

2016 TC125 and all FC Models

2017-2023 all 125-501 FE/TE/TX/FX/TC/FC Models FITS THE ALL NEW TPI 2 STROKE MODELS

GasGas

2021-2023 all Models: MC125 / MC250F / MC450F, EX300 / EX250F / EX350F / EX450F, EC300

1. Remove radiator side shrouds
2. Remove existing plastic radiator louvers
3. Line up guards with tabs on outside of radiator and push guard towards frame to seat into outside grooves. (FIG 1)
4. Mount guards to frame using supplied M6x16 bolts and washers. Check to ensure the guards are seated in the outside grooves.
5. Re-install side shrouds using stock mounting hardware. **Tip:** Remove shroud washers from shroud and place on bolts before re-install (FIG 2) This will make the install much easier.

