

# INSTALLATION INSTRUCTIONS

MADE IN  
USA



# MOUNTAINS<sup>2</sup>METAL



@MOUNTAINS2METAL

***Squatch Step***  
***2021+ Ford Bronco***



# TOOLS AND STUFF

Required tools:

- a. 13mm Socket or Wrench
- b. 4mm Allen key (SUPPLIED)

Included parts:

- A. (2) Squatch Steps (Passenger or Driver) (Front or Back)
- B. (4) M8-1.25x16 Studs
- C. (4) M8-1.25x16 Locknuts





# INSTALL

1. Thread (A) locknuts on the end of the (B) studs
2. Thread (B) studs at the end onto the step rock rail mounting bracket as shown in (F1).
3. Place (A) step onto the rock rail as shown in (F2).
4. Position the step by sliding left or right until it is in the most optimal position for you. **\*DO NOT STAND ON STEP BEFORE SECURED\***
5. Tighten the studs all the way down using the supplied (b) Allen key as shown in (F3).
6. While putting some weight on the step use a deep (a) 13mm socket or (a) 13mm wrench tighten the locknut all the way down as shown in (F4).
7. Test out the (A) step by getting in and out of the Bronco a few times. If an adjustment is needed, loosen the (C) locknut then (B) stud and return to step (3)

Thank you for supporting Mountains2Metal!



# FIGURES

