

BULLET PROOF DESIGNS – INSTALLATION GUIDE

Fantic Radiator Guards

Fits: 2025 Fantic XE 250/300

TOOLS NEEDED:

- 8mm socket or wrench
- 8mm T-handle wrench
- T30 T-handle

INSTALLATION INSTRUCTIONS:

1. Prep the Bike

- Remove side radiator shrouds using an 8mm T-handle or socket.

2. Remove OEM Hardware

- Remove radiator mounting bolts using an 8mm T-handle wrench or socket.
- Keep stock outside hardware for reuse on outer mounts.

3. Install Radiator Guards

- Place the BPD radiator guards over each radiator.
- Use the supplied M6x30 bolts and washers for inside mounting points to the frame.
- Use the stock bolts for the outside mounting points of the radiator.
- Start the 3 bolts loosely first, then tighten them evenly to align the radiator tabs.

4. Prepare for Shroud Reinstallation

- The bottom tapped hole in the guard will be used to mount the side shrouds.

5. Reinstall Components

- Reinstall radiator shrouds using the newly aligned mounting points.
- Double-check for clearance and proper alignment.

NOTES:

- No cutting or modification is required.
- Guards are designed to maximize airflow and protection.
- Re-check all hardware after first ride.

SUPPORT:

sales@bulletproofdesigns.com
www.bulletproofdesigns.com