



# BulletProof Radiator Guards

Part#'s: 22100-BL/R/S/BK

All 2020+ RR,RR-S

## Installation Instructions:



1. Remove the seat, remove radiator side shrouds, fuel tank, remove both radiator plastic front louvers.
2. Remove both upper & lower radiator frame-mount screws from both radiators.
3. Pull both radiators slightly away from their mounting posts.
4. Slide bulletproof radiator braces onto each radiator, noting the guard side cut-outs that match the radiators side plate mounts & flanges. Due to variances in the manufacturing of the radiators, some models need to leave this washer in place to fill the gap. FIG 1
5. Position the front cut-out section of each guard toward the upper-inside, which will provide clearance for the fork triple clamp.
6. Mount the radiator guards two inner 8mm screws with their washers.
7. Confirm the guards are correctly positioned & all mounting holes are aligned. Mount the two outside screws
8. Check that guards & all mounting screws are secure.
9. Check that there's enough clearance between the guards & triple clamps.
10. Reinstall radiator side shrouds, tank & seat, do not discard plastic louvers.

