




## ASSEMBLY INSTRUCTIONS

HOME Storage Cabinet (Model No. 16272, 16273)

Black    White

36 in. W x 14 in. D x 34.8 in. H  
(91.4 cm W x 35.6 cm D x 88.4 cm H)




## CONTACT INFORMATION

If you are missing any parts, have any questions, or need additional assistance in assembly, please contact our bilingual (English and Spanish) customer service department at:















Seville Classics, Inc.  
19401 Harbortgate Way Torrance, CA 90501 USA  
Telephone: (800) 323-5565 within USA  
Fax: (310) 533-3899  
Hours: 9:00am - 4:30pm (Pacific Standard Time)  
E-mail: [support@sevilleclassics.com](mailto:support@sevilleclassics.com)  
Website & Online Store: [www.sevilleclassics.com](http://www.sevilleclassics.com)















# PARTS LIST

Please check the parts carefully according to the parts list.

|                                                                                     |                                                                                      |                                                                                       |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|    |     |    |
| <b>(#1) Left Side Panel x 1 pc</b>                                                  | <b>(#9) Right Side Panel x 1 pc</b>                                                  | <b>(#3) Top Panel x 1 pc</b>                                                          |
|    |    |   |
| <b>(#4) Bottom Panel x 1 pc</b>                                                     | <b>(#8) Upper Back Panel x 1 pc</b>                                                  | <b>(#10) Bottom Back Panel x 1 pc</b>                                                 |
|  |  |  |
| <b>(#2) Door x 2 pcs</b>                                                            | <b>(#5) Middle Shelf x 3 pcs</b>                                                     | <b>(#6-D) Leveling Feet x 4 pcs</b>                                                   |
|   |   |  |
| <b>(#67) Handle x 2 pcs</b>                                                         | <b>(#14) Hinge x 4 pcs</b>                                                           | <b>(#52) Screw (M4 x 10L) x 16 pcs</b>                                                |

# PARTS LIST

Please check the parts carefully according to the parts list.

|                                                                                     |                                                                                     |                                                                                       |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|    |    |    |
| #41) Screw (M4 x 8L) x 44 pcs                                                       | #42-A) Screw (M4 x 25L) x 4 pcs                                                     | #13) Angle Bracket x 4 pcs                                                            |
|   |   |   |
| #34) Hook x 12 pcs                                                                  | #89) Screw (M10 x 20L) x 4 pcs                                                      | #21) Screwdriver x 1 pc                                                               |
|  |  |  |
| #55) Screw (M6 x 50L) x 2 pcs                                                       | #55-A) Wall Anchor x 2 pcs                                                          | #27) Washer (M4) x 2 pcs                                                              |
|  |  |  |
| #60) Anti-Tip Strap x 2 pcs                                                         | #27-B) Washer (M8) x 2 pcs                                                          | #61) Screw (M4 x 12L) x 2 pcs                                                         |


# HOME Storage Cabinet (Model No. 16272, 16273)



\*NOTE: We recommend using TWO people to assemble the cabinet.


## Step 1. Install Bottom Panel (#4) and Side Panels (#1&9)

Attach the **BOTTOM PANEL (#4)** with the **LEFT SIDE PANEL (#1)** and **RIGHT SIDE PANEL (#9)**. Line up screw holes and secure them using 8 pcs of **SCREWS M4 X 8L (#41)**.



## Step 2. Install Top Panel (#3)

Attach the **TOP PANEL (#3)** between the **LEFT SIDE PANEL (#1)** and **RIGHT SIDE PANEL (#9)**. Line up screw holes and secure them using 6 pcs of **SCREWS M4 X 8L (#41)**.




## Step 3. Install Back Panels (#8 & 10) and Leveling Feet (#6-D)

First, install the **BOTTOM BACK PANEL (#10)**. Line up the screw holes and secure it using 10 pcs of **SCREWS M4 X 8L (#41)**. Do not fully tighten screws at this stage.

Then, place the **UPPER BACK PANEL (#8)** so the bottom of the panel rests on the top of the **BOTTOM BACK PANEL (#10)**. Secure it using 12 pcs of **SCREWS M4 X 8L (#41)**. Fully tighten all screws.

Attach the 4 pcs of **LEVELING FEET (#6-D)** to the **BOTTOM PANEL (#4)** as illustrated, and hand-tighten them securely.




# HOME Storage Cabinet (Model No. 16272, 16273)



\*NOTE: We recommend using TWO people to assemble the cabinet.

## Step 4. Install Angle Brackets (#13)

Position the cabinet upright. Attach 4 pcs of **ANGLE BRACKETS (#13)** in each corner of the cabinet. Secure them using 8 pcs of **SCREWS M4 X 8L (#41)**.




## Step 5. Install Middle Shelves (#5)

Decide the height for the **MIDDLE SHELVES (#5)**, place the 4 pcs of **HOOKS (#34)** into the hook slots and push down.

Please note that each **MIDDLE SHELF (#5)** needs 4 pcs of **HOOKS (#34)** at each corner for support. When placing the hooks, make sure they are at the same height.


Place the **MIDDLE SHELVES (#5)** into the cabinet and push down onto the **HOOKS (#34)**.

**Note:** 100 lbs. maximum loading for each shelf.



## Step 6. Install Hinges (#14)

Attach the 4 pcs of **HINGES (#14)** to the **SIDE PANELS (#1&9)** as the left picture shows. Secure them using 8 pcs of **SCREWS M4 X 10L (#52)**.




# HOME Storage Cabinet (Model No. 16272, 16273)



\*NOTE: We recommend using TWO people to assemble the cabinet.


## Step 7. Install Doors (#2) and Handles (#67)

Attach the **DOORS (#2)** to **HINGES (#14)**, secure them using 8 pcs of **SCREWS M4 X 10L (#52)**. Then install the **HANDLES (#67)** on the **DOORS (#2)** with 4 pcs of **SCREWS M4 X 25L (#42-A)**.




## Step A. Doors (#2) Adjustment - Forward and Backward

If the **DOORS (#2)** interfere with the **SIDE PANELS (#1&9)** during opening/closing or exhibits excessive gaps, its front-back position can be adjusted. As the image shown below, loosen the indicated screws on the **HINGES (#14)** to adjust the **DOORS (#2)** forward or backward to the desired position, and then securely tighten the screws.



## Step B. Doors (#2) Adjustment - Up and Down

As the image shown below, loosen the indicated screws on the **HINGES (#14)** to adjust the **DOORS (#2)** vertically until its top edge is flush with the **TOP PANEL (#3)**, then securely tighten the screws.






# HOME Storage Cabinet (Model No. 16272, 16273)



\*NOTE: We recommend using TWO people to assemble the cabinet.

## Step C. Doors (#2) Adjustment - Left and Right

Use the **SCREWDRIVER (#21)** to rotate the indicated screws below of the **HINGES (#14)** to adjust the **DOORS (#2)** horizontally.





## Step 8. Install Anti-Tip Strap (#60)

A. Remove 1 pc **SCREW M4 x 8L (#41)** from the back panel.

B. Attach the **ANTI-TIP STRAP (#60)** to the back panel as the left image shows using **SCREW M4 x 12L (#61)** and **WASHER M4 (#27)**.

C. Drill a hole in the wall with a 5/16" drill bit, insert the **WALL ANCHOR (#55-A)** into the hole. Secure it using **SCREW M6 x 50L (#55)** and **WASHER M8 (#27-B)**.

Repeat steps A through C to install the other anti-tip strap.



## Step 9. Stacking two cabinets

A. Remove the **LEVELING FEET (#6-D)** of the upper cabinet. And remove plastic caps (A) from the **TOP PANEL (#3)** of the bottom cabinet.

B. Place the cabinet without leveling feet on the top of the other cabinet. Line up the screw holes between the **BOTTOM PANEL (#4)** of upper cabinet and **TOP PANEL (#3)** of bottom cabinet. Insert 4 pcs **SCREWS M10 x 20L (#89)** from bottom to top into the **BOTTOM PANEL (#4)** of the upper cabinet.

If the upper and lower door panels interfere with each other, adjust the doors following Step B.

