

USER GUIDE

Welcome! Let's setup human tracking on your 360 Mini Camera.

Contents:


2 Turn human tracking on & off

3-4 iPhone and Android Menu

5-6 Setting a home position

TURN HUMAN TRACKING ON & OFF

A. When on the live view of the camera, swipe at the bottom of the screen to change between menus.



B. Select your 360 camera on the app home screen menu. You will then need to swipe twice to get to the shown menu in the image.



C. Toggle human tracking on and off by selecting the 'Intelligent tracking' icon.

When highlighted, human tracking is active.

IPHONE AND ANDROID MENU

When in the preset position menu, it displays differently depending on your device.

iPhone



- A. Click on the number input to bring up keypad
- B. Enter number using keypad then click confirm


Note: buttons show as Setup and Call



Sometimes when entering a command, there there will be no feedback the the command has been successfully entered. This is normal.

IPHONE AND ANDROID MENU

Android



Keypad appears automatically.

Note: buttons show as Setting and Transfer




Sometimes when entering a command, there there will be no feedback the the command has been successfully entered. This is normal.

SET HOME POSITION

You will need to set a 'home' position for your camera. This will be the position the camera returns to after you move the camera or after the camera has finished tracking.


The camera will return to this position 120 seconds after the human goes out of sight. This cannot be changed.

A. Move your camera to the home position




B. Swipe twice to get to the shown menu.

C. Press 'Preset Position'.



Sometimes when entering a command, there there will be no feedback the the command has been successfully entered. This is normal.

SET HOME POSITION



D. Type 1 Setting or Setup

E. Type 65 setting or Setup

F. Type 1 setting or Setup

Home position is now set. The camera will return to the home position after 120 seconds.



Sometimes when entering a command, there there will be no feedback the the command has been successfully entered. This is normal.