

Place heavier items on the lower shelves and lighter ones on the top. Do not stand or climb on the shelving system. Do not drop heavy items on the system.

Do not move the system while loaded.

### Specifications

Dimensions: 25" W x 33" D x 60" H (56.5"H on leveling feet), 1" Pole Diameter

Weight capacity	Per shelf	Overall
On leveling feet	200 lbs. (90.7 kg)	800 lbs. (362.9 kg)
On 3"H wheels	<b>125 lbs.</b> (56.7 kg)	500 lbs. (226.8 kg)


### **Customer Service Information**

Seville Classics, Inc Telephone: (800) 323-5565 Fax: (310) 533-3899 Hours: 8:30 AM - 4:30 PM (PST) Email: Support@SevilleClassics.com Homepage: www.SevilleClassics.com

### MZ03212025

# seville classics®

Commercial-Grade **4-Tier NSF Steel Wire Tote Shelving** 25" W x 33" D x 60" H



### Model #: SHE24336B

Thank you for choosing Seville Classics! We hope that you enjoy your commercial-grade steel wire shelving! Please read through this guide for parts list, assembly instructions, frequently asked questions and further contact information.

### Parts List


Please make sure you have all the parts on this list.

Threaded end

۲

6


A. Bottom poles (4) (Threaded end)



B. Top poles (4) (Plastic cap on end)


C. Connectors (4) (May be attached to poles)

D. Shelves (4)




(0

Cap En



If you're missing parts, contact us for replacements at (800) 323-5565 or send an email to Support@SevilleClassics.com

## Assembly Instructions



STEP 1.


Screw LEVELING FEET (F) or WHEELS (G, H) into base of BOTTOM POLES (A).

Repeat for all bottom poles.

### STEP 2.

Snap SLIP SLEEVES (E) around the grooves on BOTTOM POLES (A); This will be your lowest shelf.

**TIP!** Count the number of grooves from the bottom of the pole to keep the height consistent.



STEP 3. Fit **SHELF (D)** over the top of the 4 poles and over SLIP SLEEVES (E).

Repeat STEPS 2-3 for next shelf.

TIP! If necessary, lightly tap shelves into place with a rubber mallet (not included).

STEP 4. Screw CONNECTORS (C) into top of **BOTTOM POLES (A).** 

Screw TOP POLES (B) to CONNECTORS (C).

**TIP!** Connectors may be pre-installed.

STEP 5. Repeat **STEPS 2-3** for remaining shelves.